



SPARK

Hanging Frame Manual

READ MANUAL FIRST



Safety Distance Guide



Parts Check List

Part No	Parts	Quantity	Part No	Parts	Quantity
1		1	9		4
2		1	10		2
3		1	11		2
4		1	12		2
5		2	13		4
6		2	14		4
7		2	15		2
8		2	16		8




Preparation



1




2



3


- 1. Gloves:** It is recommend that people who are willing to install the hanging frame should wear gloves to prevent injuries.
- 2. Tools:** Screwdriver is recommended to install hanging frame
- 3. Ladder:** Ladder is recommend to install the hanging frame

Hanging Frame Parts Location Guide (Please refer to the previous page)




Assembly Guide

Step 1




Step 2




Assembly Guide

Step 3




Step 4




Assembly Guide

Step 5




Step 6




Assembly Guide

Step 7



Congratulations you have successfully installed Hanging Frame!



Weight Limit = 45Kg (99.2lbs)



WARNING

- This hanging frame is for family domestic use only.
- This swing set is designed for use by children 3-9 years of age weighing no more than 45Kgs (99lbs)
- Children of all ages must be supervised by an adult at all times when using this hanging frame.
- Adult assembly of this hanging frame is required. Two adults are recommended for assembly.

1. Read and understand enclosed safety information before assembly and use of the hanging frame.
2. Lateral clearance is essential. The hanging frame should be placed not less than 2m (6 feet 6 inches) from any structure or obstruction ie. a fence, garage, house, shed, overhead branches, clothes line etc.
3. Anchor the hanging frame using the wiggling anchor pegs provided to prevent overturning or lifting. The anchors should be placed level with or under the ground in order to reduce the tripping hazards.
4. Never place the hanging frame under or near powerlines.
5. Never place the hanging frame inside a garage or basement or under any structure.
6. Always position the hanging frame where it can be seen from the house.
7. This hanging frame is designed to be used by one child at one time.
8. Do not allow additional items to be attached to the hanging frame such as ropes, chains, cords, or other items not designed for use.
9. Do not use the hanging frame when it is wet as it will become slippery and serious injury may result.
10. Do not wear apparel such as hats with chin straps, helmets, scarves, garments with pull strings and other items of loose clothing while using this hanging frame as they can cause serious injury.
11. Do not jump from the hanging frame.

MAINTENANCE INSTRUCTION

To maximise the life of your hanging frame, make sure your children enjoy your hanging frame safely. It is important to check and inspect the following regularly before each use of the hanging frame, and carry out necessary maintenance immediately. Nuts and Bolts: Check before each use for tightness and tighten if required. Replace any damaged, distorted or missing fasteners immediately.

Plastic components: Check before each use for deterioration. Replace immediately if cracked or damaged. Use only genuine iTech Trampolines's replacement parts. Metal components: Check before each use for corrosion, cracking, tears, distortion or other damage. Replace immediately if these conditions exist. In particular, check the Braces on the top tubes and the Brackets on the Glide Ride, as these can be damaged through improper use / or excessive lateral movement. Oil all metallic moving parts at least one time a month.



CAUTION

Do not allow children to use the hanging frame until the maintenance has been carried out. The use of hanging frame not in first class condition exposes the child to the risk of injury. As a parent, supervisor, owner or guardian, it is your responsibility to ensure that the hanging frame is properly maintained. Spare parts are available through Customer Service centre.

HANGING FRAME LIMITED WARRANTY

Spark Trampolines warrants its hanging frame products to be free from defects in material and workmanship under normal use and service conditions. The various components of the hanging frame are warranted against defects and workmanship for 6 months.

All warranty coverage extends only to the original retail purchaser from the date of purchase. Spark Trampolines' obligation under this Warranty is limited to replacing or repairing, at Spark Trampolines's option, the product or parts therein. For efficient processing of your enquiry please have relevant date of purchase, retailer name you purchased the item from and the brand on the product. This warranty does not extend to any damage to a product caused by abuse, improper or abnormal usage (as detailed in this instruction manual), or repairs not provided by SPARK Trampolines or Flybar. Nor does this warranty extend to products used for commercial or rental purposes. This warranty does not cover ordinary wear, tear and weathering, failure to follow directions, improper installation, improper maintenance or acts of God (such as damage caused by storms, lightning and by snow or ice). No other Warranty beyond that specifically set forth above is authorised by Spark Trampolines.

Our sales and service centre has been set up to provide assembly assistance, replacement parts and accessories, and to efficiently handle all warranty related matters. Call 1300 782 661 or Email: info@sparktrampolines.com.au

